



| | | | |
|-------------|---------|----------|-----|
| VOR/DME VLA | APP CRS | Rwy Idg | N/A |
| 114.3 | 209° | TDZE | N/A |
| Chan 90 | | Apt Elev | 541 |

VOR-A

GREENVILLE (GRV)

| | | | |
|--|---|--|---|
| DME required. | | MISSED APPROACH: Climbing left turn to 2400 direct VLA VOR/DME and hold. | |
|  NA | Circling NA to Rwys 9 and 27. When local altimeter setting not received, Use Salem-Leckrone altimeter setting and increase all MDAs 60 feet, and increase Circling Cat D visibility ¼ SM. | | |
| AWOS-A 123.05 | SLO AWOS-3 118.525 | KANSAS CITY CENTER 124.3 269.15 | UNICOM 123.05 (CTAF)  |

