

NDB AHQ	APP CRS	Rwy Idg	4100
400	205°	TDZE	1224
		Apt Elev	1224

NDB RWY 20

WAHOO MUNI (AHQ)

<div><div>NA</div><div>Circling to Rwy 13-31 NA. Use Fremont altimeter setting, when not received, use Lincoln altimeter setting and increase all MDA 40 feet.</div></div>	<div>MISSED APPROACH: Climbing right turn to 3500 in AHQ NDB holding pattern.</div>
--	---

AWOS-3P 125.975	OMAHA APP CON 120.1 354.05	UNICOM 122.7 (CTAF) 1
--------------------	-------------------------------	---------------------------------

