

VOR or TACAN RWY 20
SPRINGFIELD-BRANSON NATIONAL (SGF)

MISSED APPROACH: Climb to 3000 then right turn to intercept SGF R-206 to BLUE INT/SGF 21.8 DME and hold.

VOR or TACAN RWY 20