

VOR RWY 13
COLUMBIA RGNL (COU)

MISSED APPROACH: Climb to 1900 then climbing right turn to 2700 on COU VOR/DME R-333 to SAPPY INT/COU 6 DME and hold.

MSA COU 25 NM

3100

IAF HALLSVILLE 114.2 HLW Chan 89

Procedure NA for arrivals on HLV VORTAC airway radials 177 CW 203.

R-333

(IF) ANNOT INT 2700 153° (6)

R-226

2900 NoPT 226° (12.2)

R-203

R-196

153° 1 min 333°

(IAF) SAPPY INT 2700 333° (6)

BATYE INT 2700 985

COACT COU 2700 967

2700 to SAPPY 333° (6)

2700 to VOR/DME 349° (13.2)

COLUMBIA 110.2 COU Chan 39

Procedure NA for arrivals at COU VOR/DME on V12 southeast.

ELEV 889 TDZE 889

BANTON

One Minute Holding Pattern

SAPPY INT COU 333° 153° 1880

BATYE INT COU 1880

COU 1.9 COACT COU 1.1 COU VOR/DME

2700 333° 153° 153° 153°

22 NM 19 NM 0.8 0.1

TCH 45

COU R-333

ELEV 889 D TDZE 889

153° 5 NM from FAF

949

13 500 X 100 20

150

600 X 150

TWR 960

HIRL Rwy 2-20 1

MIRL Rwy 13-31 1

REIL Rwy 20 1

REIL Rws 13 and 31

FAF to MAP 4.9 NM

Knots	60	90	120	150	180
Min:Sec	4:54	3:16	2:27	1:58	1:38