

VOR RWY 14  
MC ALLEN MILLER INTL (MFE)

MALSR

**MISSED APPROACH:** Climb to 1000 then climbing left turn to 2000 direct MFE VOR/DME and hold.

ATIS <b>128.5</b>	VALLEY APP CON <b>121.0 377.2</b>	MC ALLEN TOWER ★ <b>118.5 (CTAF) 0 256.9</b>	GND CON <b>121.8</b>	UNICOM <b>122.95</b>
----------------------	--------------------------------------	---	-------------------------	-------------------------

ADF or DME REQUIRED

