



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 4: Climbing right turn heading 110°, maintain 1600, intercept MCF R-080 outbound, expect radar vectors. Expect clearance to filed altitude within 10 min after departure.

TAKE-OFF RWY 22: Climbing left turn heading 160°, maintain 1600, intercept MCF R-190 outbound, expect radar vectors. Expect clearance to filed altitude within 10 min after departure.