



ARRIVAL ROUTE DESCRIPTION

ANAHO TRANSITION (ANAHO.SLMR4)

CARVV TRANSITION (CARVV.SLMR4)

CRASY TRANSITION (CRASY.SLMR4)

DONNR TRANSITION (DONNR.SIMMR4)

WEBGO TRANSITION (WEBGO.SLMR4)

From SLMMR on track 239° to cross POZUR at or above 8000.

SOUTH TRANSITION RUNWAYS 17L/R: From POZUR on track 238° to cross TENCO at or above 4500 and at 210K, then on track 223° to cross ZIMAM at or above 3000 and at 210K. Expect assigned instrument approach procedure.

NORTH TRANSITION RUNWAYS 35L/R: From POZUR on track 240° to NORTH TRANSITION RUNWAYS 35L/R, then on track 219° to cross PKAAY at or above 6000 and at 210K, then on track 221° to THANN, then on track 168° to cross BANZA at 4000 and at 210K, then on track 168° to ZITUL, then on track 168°. Expect RADAR vectors to final approach course.

NOTE: RADAR required.

NOTE: RNAV 1.

NOTE: DME/DME/IRU or GPS required.

NOTE: Expect to receive transition (south/north) and "descend via" clearance from Oakland Center. Northern California Tracon will assign landing runway.

NOTE: South transition indicates Rwy 17L/R.

NOTE: North transition indicates Rwy 35L/R.

NOTE: WEBGO and CARW transition ATC assigned only.