



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 3L/R: Climb tracking 030°. Abeam ZOBEG (LUF TACAN R-030/4 DME) turn left direct LUF. Cross LUF at 5000 and proceed outbound via LUF R-175 to 29.9 DME (BUSCO), cross LUF 18 DME at 5000, cross BUSCO at or below 8000 (or as assigned by ATC). Then via assigned route/transition.

TAKE-OFF RWY 21L/R: Climb tracking 211°. Abeam EZRUN (LUF TACAN R-211/8 DME) turn left heading 140° to intercept and proceed via LUF R-175 to 29.9 DME (BUSCO). Cross abeam EZRUN at or below 5000, cross LUF 18 DME at 5000, cross BUSCO at or below 8000, (or as assigned by ATC). Then via assigned route/transition.

BUGGS TRANSITION (BUSCO9•BUGGS): Proceed via LUF R-175 to 37.5 DME (ZIRUK). Intercept and proceed via BXX VORTAC R-138 to 55.8 DME (BUGGS). Cross LUF R-175/33 DME at 8000, cross BXX R-138/40 DME at 9000, cross BUGGS at and maintain 9000 (or as assigned by ATC). **CAUTION:** Aircraft exiting BUGGS at 8000.

FLIER TRANSITION (BUSCO9•FLIER): Intercept and proceed via the BXX VORTAC R-129 to 54.7 DME (FLIER). Cross BXX 35 DME at 8000, cross BXX 40 DME at 9000, cross FLIER at and maintain 9000 (or as assigned by ATC).