

VOR/DME TKA <b>116.2</b> Chan <b>109</b>	APP CRS <b>352°</b>	Rwy Idg <b>3500</b> TDZE <b>363</b> Apt Elev <b>365</b>
--	------------------------	---

VOR RWY 1  
TALKEETNA (TKA)(PATK)

DME required.

- |          |  |
|----------|--|
| <b>T</b> | Circling NA east of Rwy 1-19.  |
| <b>A</b> | Rwy 1 helicopter visibility reduction below 1 SM NA.<br>Straight-in Rwy 1 NA at night, Circling Rwy 1 NA at night. |

MISSED APPROACH: Climb to 2100 on TKA  
VOR/DME R-352 then climbing left turn to 3200  
direct TKA VOR/DME and hold.

AFIS <b>135.2</b>	ANCHORAGE CENTER <b>125.55 254.3</b>	TALKEETNA RADIO <b>123.6 (CTAF) 0</b>	UNICOM <b>123.0</b>
----------------------	---	--	------------------------

