


VOR/DME VLA	APP CRS	Rwy Idg	N/A
114.3	209°	TDZE	N/A
Chan 90		Apt Elev	541

VOR-A

GREENVILLE (GRE)

DME required.		MISSED APPROACH: Climbing left turn to 2400 direct VLA VOR/DME and hold.	
 NA	Circling NA to Rwys 9 and 27. When local altimeter setting not received, Use Salem-Leckrone altimeter setting and increase all MDAs 60 feet, and increase Circling Cat D visibility ¼ SM.		
AWOS-A 123.05	SLO AWOS-3 118.525	KANSAS CITY CENTER 124.3 269.15	UNICOM 123.05(CTAF) 0

