

LOC I-SPW 110.9	APP CRS 121°	Rwy Idg TDZE Apt Elev	6001 1339 1339
---------------------------	------------------------	-----------------------------	---

ILS or LOC RWY 12
SPENCER MUNI (SPW)

NA
-32°C

For Inop ALS, increase S-LOC 12 Cats C/D visibility to 1½ SM. When local altimeter setting not received, use Estherville altimeter setting: increase DA and all MDAs 60 feet, increase visibility S-LOC 12 Cats C and D and Circling Cats C and D ½ SM. For inop ALS, when using Estherville altimeter setting, increase S-ILS 12 all Cats visibility to 1 SM and S-LOC 12 Cats C/D visibility to 1½ SM. ADF or DME required.

MALSR
A5

MISSED APPROACH: Climb to 3500 then right turn direct SPW VOR/DME, then via SPW VOR/DME R-302 to SNORE LOM/SPW VOR/DME 7 DME and hold.

ASOS 126.625	MINNEAPOLIS CENTER 127.75 257.7	UNICOM 123.0 (CTAF)
------------------------	---	-------------------------------

