

LOC RWY 35
NORWOOD MEMORIAL (OWD)

MISSED APPROACH: Climbing left turn to 3000 and BOS VOR/DME R-240 to MILIS INT/20.9 DME and hold, continue climb-in-hold to 3000.

Procedure NA for arrivals
on PVD VOR/DME airway
radials 093 CW 115.

[illegible]