


ILS or LOC/DME RWY 31
ATLANTIC CITY INTL (ACY)



DME REQUIRED

500 ↑	2000 hdg 130°	ACY R-090	SMITS △	Use I-ACY DME when on localizer course. VGSJ and ILS glidepath not coincident (VGSJ Angle 3.00°/TCH 69°).					One Minute Holding Pattern
CATEGORY	A		B		C		D		E
S-ILS 31	264/40 200 (200-¾)								
S-LOC 31	520/50 456 (500-1)		520/60 456 (500-1¼)		520-1½		456 (500-1½)		
CIRCLING	540-1 465 (500-1)		540-1½ 465 (500-1½)		640-2 565 (600-2)		760-2½ 685 (700-2½)		