



DEPARTURE ROUTE DESCRIPTION

JETS:

TAKEOFF RUNWAYS 13L/R: Climb on heading 133°, for vector to appropriate route. Maintain ATC assigned altitude and expect filed altitude 10 minutes after departure.

TAKEOFF RUNWAYS 31L/R: Climb on heading 313° until the LVF or OVW LOCALIZER 5.5 DME, then right turn heading 013°, for vector to the appropriate route, maintain ATC assigned altitude, expect filed altitude 10 minutes after departure.

- GREGG COUNTY TRANSITION (GARL9.GGG): From over TTT VOR/DME on TTT R-094 to ROCKK, then on GGG R-279 to GGG VORTAC.
- PARIS TRANSITION (GARL9.PRX): From over TTT VOR/DME on TTT R-064 to ECKEY, then on PRX R-221 to PRX VOR/DME.
- SOLDO TRANSITION (GARL9.SOLDO): From over TTT VOR/DME on TTT R-084 to SOLDO.
- TEXARKANA TRANSITION (GARL9.TXK): From over TTT VOR/DME on TTT R-074 to SHERO, then on TXK R-244 to TXK VORTAC.
- TYLER TRANSITION (GARL9.TYR): From over TTT VOR/DME on TTT R-094 to ROCKK, then on TYR R-303 to TYR VOR/DME.