



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 16: Climb on heading 162° to 2500 before turning left.  
TAKEOFF RUNWAY 34: Climb on heading 342° to 1400 before turning southeast bound.

When entering controlled airspace, fly assigned heading and altitude, for vector to appropriate route.

BELCHER TRANSITION (DALL7.EIC): From over TTT VOR/DME on TTT R-094 to POTEN, then on EIC R-259 to EIC VORTAC.  
LITTLE ROCK TRANSITION (DALL7.LIT): From over TTT VOR/DME on TTT R-064 to ORTRO, then on LIT R-235 to LIT VORTAC.  
SAWMILL TRANSITION (DALL7.SWB): From over TTT VOR/DME on TTT R-094 to POTEN, then on EIC R-259 to TEKBE, then on SWB R-291 to SWB VOR/DME.  
SOLDO TRANSITION (DALL7.SOLDO): From over TTT VOR/DME on TTT R-084 to SOLDO.  
TEXARKANA TRANSITION (DALL7.TXK): From over TTT VOR/DME on TTT R-074 to SHERO, then on TXK R-244 to TXK VORTAC.