



VORTAC SAC 115.2 Chan 99	APP CRS 016°	Rwy Idg 5503 TDZE 21 Apt Elev 24
--	------------------------	---

VOR RWY 2
SACRAMENTO EXECUTIVE (SAC)

 <p>When local altimeter setting not received, use Sacramento Intl altimeter setting and increase all MDA 40 feet.</p>	<p>MALSR</p> 	<p>MISSED APPROACH: Climbing left turn to 1600 direct SAC VORTAC and hold.</p>
---	--	--

ATIS 125.5	NORCAL APP CON 125.25 257.9	EXEC TOWER ★ 119.5 (CTAF) 0 278.8	GND CON 125.0	UNICOM 122.95
----------------------	---------------------------------------	---	-------------------------	-------------------------

