

VORTAC SNS <b>117.3</b> Chan <b>120</b>	APP CRS <b>314°</b>	Rwy Idg TDZE Apt Elev <b>N/A</b> <b>N/A</b> <b>163</b>
---	------------------------	---

VOR-A

WATSONVILLE MUNI (WVI)

⚠

⚠

Circling NA west of Rwy 2-20. When local altimeter setting not received, use Monterey altimeter setting and increase all MDA's 80 feet.  
DME required. Circling Rwy 27 NA at night.

MISSED APPROACH: Climbing left turn to 5000 direct SNS VORTAC and hold, continue climb-in-hold to 5000.

ASOS <b>132.275</b>	NORCAL APP CON <b>127.15 307.125</b>	UNICOM <b>122.8</b> (CTAF) <b>0</b>
------------------------	---	--

