

AIRPORT DIAGRAM

GREAT FALLS INTL (GTF)
GREAT FALLS, MONTANA

D

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

U.S.
CUSTOMS

A map of the Montana ANG area. The map shows a large black area representing the Montana ANG. A road runs diagonally from the top left to the bottom right. A horizontal line with a dashed line above it represents a boundary or road. A star is located in the top right corner. A building labeled 'FIRE STATION' is located near the road. A building labeled 'TERMINAL' is located to the right of the fire station. A building labeled 'TWR 3818' is located below the terminal. A building labeled 'ANG HANGAR' is located at the bottom left. A road labeled 'A2' and 'R1' is shown. A road labeled 'A3' is shown. A road labeled 'A' is shown. A road labeled 'R2' is shown. A road labeled 'O' is shown. A road labeled '47°' is shown. A road labeled 'MONTANA ANG' is shown.

RWY 03-21
PCN 58 F/B/X/T
S-116, D-225, 2D-424, 2D/2D2-915
RWY 17-35
PCN 30 F/B/X/T
S-87, D-140, 2D-245, 2D/2D2-245

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

FIELD
ELEV
3680

ARM/DEARM AREA

AIRPORT DIAGRAM

GREAT FALLS, MONTANA
GREAT FALLS INTL (GTF)

NW-1, 03 DEC 2020 to 31 DEC 2020