

<div>▼</div>	<div>DEPARTURE ROUTE DESCRIPTION</div> <div><div>TAKEOFF RWY 13R: Turn right heading 163° not later than 0.7 DME outbound on the I-DPX localizer southeast course, to intercept and climb on the CVE R-139 and expect vectors to appropriate route, unless otherwise advised maintain 5000 and expect filed altitude 10 minutes after departure.</div><div><div>ARDMORE TRANSITION (KRUMM8.ADM): From over FUZ VORTAC on FUZ R-348 to LOWGN, then on ADM R-179 to ADM VORTAC.</div><div>BLECO TRANSITION (KRUMM8.BLECO): From over FUZ VORTAC on FUZ R-360 to BLECO.</div><div>EAKER TRANSITION (KRUMM8.EAKER): From over FUZ VORTAC on FUZ R-012 to EAKER.</div><div>GRABE TRANSITION (KRUMM8.GRABE): From over FUZ VORTAC on FUZ R-012 to GRABE.</div><div>OKMULGEE TRANSITION (KRUMM8.OKM): From over FUZ VORTAC on FUZ R-012 to EAKER, then on OKM R-196 to OKM VOR/DME.</div><div>ROLLS TRANSITION (KRUMM8.ROLLS): From over FUZ VORTAC on FUZ R-348 to LOWGN, then on ADM R-179 to ADM VORTAC, then on ADM R-303 to ROLLs.</div><div>TULSA TRANSITION (KRUMM8.TUL): From over FUZ VORTAC on FUZ R-360 to ZEMMA, then on TUL R-201 to TUL VORTAC.</div><div>WILL ROGERS TRANSITION (KRUMM8.IRW): From over FUZ VORTAC on FUZ R-360 to ZEMMA, then on IRW R-145 to IRW VORTAC.</div><div>ZEMMA TRANSITION (KRUMM8.ZEMMA): From over FUZ VORTAC on FUZ R-360 to ZEMMA.</div></div></div>
--------------	---