

<div>▼</div>	<div>DEPARTURE ROUTE DESCRIPTION</div>
<div>TAKEOFF RUNWAY 13: Climb on heading 129° to 1800 before turning westbound, thence. . .</div> <div>TAKEOFF RUNWAY 17: Climb on heading 174° to 2600 before turning westbound, thence. . .</div> <div>TAKEOFF RUNWAY 31: Climb on heading 309° to 1500 before turning southbound, thence. . .</div> <div>TAKEOFF RUNWAY 35: Climb on heading 354° to 1400 before turning southbound, thence. . .</div> <div>. . . fly assigned heading and altitude, for vector to appropriate route.</div>	
<div>ABILENE TRANSITION (WORTH4.ABI): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC.</div> <div>CHILDRESS TRANSITION (WORTH4.CDS): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC.</div> <div>CORONA TRANSITION (WORTH4.CNX): From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC.</div> <div>LUBBOCK TRANSITION (WORTH4.LBB): From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC.</div> <div>MILLSAP TRANSITION (WORTH4.MQP): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC.</div> <div>PANHANDLE TRANSITION (WORTH4.PNH): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC.</div> <div>PODDE TRANSITION (WORTH4.PODDE): From over TTT VOR/DME on TTT R-250 to PODDE.</div> <div>TEXICO TRANSITION (WORTH4.TXO): From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.</div>	