

▼	DEPARTURE ROUTE DESCRIPTION
	<p><u>TAKEOFF RUNWAYS 16, 17:</u> Climb on heading 164° to 1600 before proceeding on course, thence. . . .</p> <p>. . . .fly assigned heading and altitude, for vector to appropriate route.</p> <p><u>ABILENE TRANSITION (WORTH5.ABI):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC.</p> <p><u>CHILDRESS TRANSITION (WORTH5.CDS):</u> From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC.</p> <p><u>CORONA TRANSITION (WORTH5.CNX):</u> From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC.</p> <p><u>LUBBOCK TRANSITION (WORTH5.LBB):</u> From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC.</p> <p><u>MILLSAP TRANSITION (WORTH5.MQP):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC.</p> <p><u>PANHANDLE TRANSITION (WORTH5.PNH):</u> From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC.</p> <p><u>PODDE TRANSITION (WORTH5.PODDE):</u> From over TTT VOR/DME on TTT R-250 to PODDE.</p> <p><u>TEXICO TRANSITION (WORTH5.TXO):</u> From over TTT VOR/DME on TTT R-264 to KIRST, then on LBB R-102 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.</p>