

DEPARTURE ROUTE DESCRIPTION

TAKEOFF RWY 10L: Climb heading 099° to 520, then direct CRRMN, then via track 154° to BUFT, then right turn via track 244° to SHRKY, then via depicted route to LMORE. Thence. . . .

TAKEOFF RWY 14: Climb heading 141° to 520, then right turn direct BLNKT, then via depicted route to LMORE. Thence. . . .

TAKEOFF RWY 28R: Climb heading 279° to 520, then direct CRYER, then via depicted route to LMORE. Thence. . . .

TAKEOFF RWY 32: Climb heading 321° to 520, then left turn direct CRYER, then via depicted route to LMORE. Thence. . . .

. . . . via depicted route to DONVN. Maintain 4000 or as assigned by ATC. Expect clearance to filed altitude within 10 minutes after departure.

MKYDYG TRANSITION (LMORE2.MKYDYG)




TAKEOFF MINIMUMS:
Rwy 10R, 28L: NA-ATC.
Rwy 14, 10L, 32: Standard with minimum climb of 500' per NM to 520.
Rwy 28R: Standard with minimum climb of 500' per NM to 520. ATC climb of 500' per NM to 2500.

NOTE: Chart not to scale.

TOP ALTITUDE:
4000

- NOTE: For Turbojets only.
- NOTE: If unable to accept minimum climb rates, advise ATC on initial contact.
- NOTE: Transponder code will be issued via PDC or Palm Beach CLNC DEL.
- NOTE: DME/DME/IRU or GPS required.
- NOTE: RADAR required.
- NOTE: RNAV 1.
- NOTE: For non-GPS equipped aircraft: PHK and PBI DMEs must be operational for takeoff Rwy 10L.
- NOTE: FLL DME must be operational for takeoff Rwy 14.



LMORE TWO DEPARTURE (RNAV)

PALM BEACH INTL (PBI)
WEST PALM BEACH, FLORIDA

LMORE TWO DEPARTURE (RNAV)

WEST PALM BEACH, FLORIDA
PALM BEACH INTL (PBI)