

VOR RWY 13
COLUMBIA RGNL (COU)

MISSED APPROACH: Climb to 1900 then climbing right turn to 2700 on COU VOR/DME R-333 to SAPPY INT/COU 6 DME and hold.

One Minute Holding Pattern

SAPPY INT COU 6

BATYE INT COU 3.8

COU 1.9

COACT COU 1.1

COU VOR/DME

INT

2700 ← 333°
153° →

1753°

3.31°
TCH 45

1880

2.2 NM

1.9 NM

0.8 NM

0.1 NM

ELEV 889 D TDZE 889

153° 5 NM from FAF

1300 X 100

6800 X 150

1300 X 100

949

TWR 960

HIRL Rwy 2-20

MIRL Rwy 13-31

REIL Rwy 20

REIL Rws 13 and 31

FAF to M4.9 NM

	60	90	120	150	180
Knots	60	90	120	150	180
Min:Sec	4:54	3:16	2:27	1:58	1:38