



VOR RWY 13L
VICTORIA RGNL (VCT)

MALSR

MISSED APPROACH:
Climbing left turn to 2200 direct
VCT VOR/DME and hold,
continue climb-in-hold to 2200.



GND CON
120.525 239.25



VCT VOR/DME

22

VCT



28°51'N-96°55'W

VICTORIA RGNL (VCT)
VOR RWY 13L